

Inserti maschi RIVBOLT

RIVBOLT male rivet nuts

BFTC

36700

■ **Acciaio**


Steel

Fusto cilindrico

Cylindrical shank

Testa tonda

Dome head



d	L		T	k	SS	L ₁	L ₂	Tipo	Codice		
mm	mm	mm	mm	max	mm	mm	mm	Model	Item code	pz	pz
M4	15.0	5.5	8.0	0.5	0.5 ÷ 2.0	8.5	4.0	BFTC1502004	2586100	250S	8000
	15.0				2.0 ÷ 3.0	9.5	BFTC1503004	2586200	250S	8000	
M5	15.0	6.6	9.0	0.8	0.5 ÷ 2.0	10.0	5.0	BFTC1502005	1680000	250S	6000
	15.0				2.0 ÷ 4.8	11.0	BFTC1503805	2586500	250S	4000	
M6	15.0	7.8	10.0	1.0	0.5 ÷ 2.5	11.0	6.0	BFTC1502506	1680100	250S	4000
	15.0				2.5 ÷ 4.0	12.5	BFTC1504006	2586800	250S	4000	
M8	20.0	9.9	12.0	1.0	1.0 ÷ 3.0	14.0	8.0	BF-IC2003008	2587100	250N	2000
	20.0				3.0 ÷ 5.0	16.0	BFTC2005008	2587200	250N	2000	

BFTE

36700

■ **Acciaio**


Steel

Fusto esagonale


Hexagonal shank

Testa tonda

Dome head



d	L		T	k	SS	L ₁	L ₂	Tipo	Codice		
mm	mm	mm	mm	max	mm	mm	mm	Model	Item code	pz	pz
M5	15.0	6.9	10.0	1.0	0.5 ÷ 3.0	11.0	6.0	BFTE1503005	5159300	-	-
M6	15.0	8.9	13.0	1.5	0.5 ÷ 3.0	13.0	8.0	BFTE1503006	5159200	-	-
M8	20.0	10.9	16.0	1.5	0.5 ÷ 3.0	14.0	9.0	BFTE2003008	5159400	-	-



L'inserto prigioniero maschio si utilizza quando si ha la necessità di creare un perno filettato per avvitare un dado.
Male rivet nut is used when you have the need to create a threaded bolt to screw a nut.

Applicazione
Application



d			Kg	N	Kgm	Nm
mm	mm	mm				
M4	5.5		408	4000	0.4	4
M5	6.6	6.9	714	7000	0.7	7
M6	7.8	8.9	1019	10000	1.0	10
M8	9.9	10.9	2854	28000	3.0	30